



Spa Pool Start Up Kit – Bromine

Important Tip: Always add chemicals to water, not water to chemicals

When filling, add 25ml of Crystal Water Stain & Scale Control. This will help clean the scale off the pipes.

1. Allow water to circulate for approximately 1 hour then add 250g of Calcium Hardener with filter running, wait for 20 minutes.
2. Add 250-400g of PH Buffer with filter running, wait for 20 minutes.
3. Test pH and adjust as necessary using either pH Increase to raise or pH Decrease to lower the level (using dessertspoon amounts).
4. After 30 minutes, add five Bromine Tablets to the adjustable spa floating dispenser in the pool. Use AquaChek Spa 6:1 Test Strips to check that a 4-6 ppm Free Bromine residual is maintained.

Daily

- Test and adjust pH accordingly – 7.4-7.6 is ideal
- Test Bromine levels. Adjust dispenser (if required)

Weekly

- Remove the floating dispenser. Run your spa for 30 minutes
- Super chlorinate (shock dose) the pool with 50g per 1,000L Spa Chlor
- In between weekly shock dosing, add 10ml of CW Stain & Scale Control to protect your spa

If required

- Check and clean cartridge filter with CW Pool & Spa Filter Cleaner
- Use CW No Foam to control foaming
- CW Velvet Touch water enhancer giving the water a soft, velvety feel to the water. Clarifies and gives protection against corrosion
- CW Crystal Clear eliminates suspended dirt and organic matter that encourages bacteria and algae growth

Every 6-8 weeks

- Change the water (depending on use)
- Clean cartridge with CW Pool & Spa Filter Cleaner